

## **GS20(X) Optional Accessories – Mounting Kits**

## **DIN Rail Mounting**

Frame A, B, and C GS20 drives can be DIN rail mounted using a DIN rail mounting kit. One kit is used for A and B frame drives, while a second kit is used for C frame drives. Please see the GS20(X) User Manual for additional information and installation instructions.

GS20 D	IN Rail N	<b>Nounting Com</b>	patibility
Drive Model	Frame	DIN Rail Kit	Price
GS21-10P2	A1	GS20A-DR-AB	
GS21-20P2	A1		
GS23-20P2	A1		
GS23-20P5	A2		
GS21-10P5	A3		
GS21-20P5	A3		
GS23-40P5	A4		
GS23-21P0	A5		
GS23-41P0	A5		
GS23-51P0	A5		
GS23-22P0	B1		
GS23-42P0	B1		
GS23-52P0	B1		
GS21-21P0	B2		
GS21-11P0	C1	GS20A-DR-C	
GS21-22P0	C1		
GS21-23P0	C1		
GS23-23P0	C1		
GS23-25P0	C1		
GS23-43P0	C1		
GS23-45P0	C1		
GS23-53P0	C1		
GS23-55P0	C1		





## **GS20(X) Optional Accessories – Mounting Kits**

## **Mounting Adapter Plate**

The mounting adapter plate can be used to change the wiring orientation for the GS20 series and provides flexibility for installation. This accessory changes the wiring method from the "bottom-mains input/ bottom-motor output" to the "top-mains input/bottom-motor output" for GS20. Use the table below to select the correct mounting plate for your drive. Please see the GS20(X) User Manual for additional information and installation instructions.

GS20 M	ounting I	Adapter Comp	atibility
Drive Model	Frame	Mounting Plate	Price
GS21-10P2	A1	GS20A-MP-AB	
GS21-20P2	A1		
GS23-20P2	A1		
GS23-20P5	A2		
GS21-10P5	A3		
GS21-20P5	A3		
GS23-40P5	A4		
GS23-21P0	A5		
GS23-41P0	A5		
GS23-51P0	A5		
GS23-22P0	B1		
GS23-42P0	B1		
GS23-52P0	B1		
GS21-21P0	B2		
GS21-11P0	C1	GS20A-MP-C	
GS21-22P0	C1		
GS21-23P0	C1		
GS23-23P0	C1		
GS23-25P0	C1		
GS23-43P0	C1		
GS23-45P0	C1		
GS23-53P0	C1		
GS23-55P0	C1		

