## **Properties** Pipe Clamp Adapters



## Overview

- For use with ProSense adjustable immersion thermocouple and RTD sensors
- Available in adjustable diameters from 11/16 to 7 inches
- Provides an easy means of sensing temperature on the outside of a pipe



Shown with optional adjustable immersion sensor

Pipe Clamp Adapters for ProSense Adjustable Immersion Sensors						
Part Number	Description	Pcs/ Pkg	Wt(lb)	Price		
PCA-125	ProSense pipe clamp adapter, 11/16 to 1-1/4 inch adjustable diameter, 2-inch attached bayonet adapter with 7/16 inch outside diameter and 9/32 inch inside diameter. Use with Prosense adjustable immersion sensors.	1	0.1			
PCA-200	ProSense pipe clamp adapter with 1-1/16 to 2 inch adjustable diameter, 2-inch attached bayonet adapter with 7/16 inch outside diameter and 9/32 inch inside diameter. Use with Prosense adjustable immersion sensors.	1	0.1			
PCA-300	ProSense pipe clamp adapter with 2-1/16 to 3 inch adjustable diameter, 2-inch attached bayonet adapter with 7/16 inch outside diameter and 9/32 inch inside diameter. Use with Prosense adjustable immersion sensors.	1	0.1			
PCA-425	ProSense pipe clamp adapter with 3-5/16 to 4-1/4 inch adjustable diameter, 2-inch attached bayonet adapter with 7/16 inch outside diameter and 9/32 inch inside diameter. Use with Prosense adjustable immersion sensors.	1	0.1			
PCA-500	ProSense pipe clamp adapter with 4-1/8 to 7 inch adjustable diameter, 2-inch attached bayonet adapter with 7/16 inch outside diameter and 9/32 inch inside diameter. Use with Prosense adjustable immersion sensors.	1	0.1			

## **Dimensions**

PCA-300

## inches [mm]




TABLE A					
PART NUMBER	DIM "A"	FITS PIPE SIZES			
PCA-125	Ø0.68-1.25 [Ø17.2-31.7]	1/2 TO 3/4 NPS			
PCA-200	ø1.06-2.00 [ø26.9-50.8]	1 TO 1-1/2 NPS			
PCA-300	ø2.06-3.00 [ø52.3-76.2]	2 TO 2-1/2 NPS			
PCA-425	ø3.31-4.25 [ø84.1-108.0]	3 TO 3-1/2 NPS			
PCA-500	ø4.12-7.00 [ø104.6-177.8]	4 TO 6 NPS			