
## Serial Remote I/O Master/Slave Modules



#### **Overview**

The DL405 offers full-size remote I/O. The goal of remote I/O is to reduce wiring costs by allowing I/O points to be located near the devices they are controlling. The chart at the bottom of this page shows the capacity for each CPU. The D4-454 has the D4-RM functionality built into the 25-pin port directly on the CPU. However, you can also choose to use the D4-RM discussed here. Here's how it works: A special module called the Remote Master is placed in the CPU base. This Master module controls up to seven Remote Slaves. The Remote Slaves are connected to the Master in a daisy-chain manner over a twisted pair communication cable (maximum length of 3,300 feet or 1000 meter). Each Remote Slave attaches to a DL405 base (any size). Standard DL405 modules populate the remote bases.





You can assign normal input and output addresses to the remote points, or you can assign special remote I/O addresses. The Remote Master sends the remote I/O information to the CPU. The communication between the Remote Master and the CPU is asynchronous to the CPU scan. For this reason, remote I/O applications should be limited to those that do not require the remote I/O points to be updated with every CPU scan.

	D4-454
Maximum number of remote masters supported	3*
Maximum I/O points supported	1536
Maximum I/O points supported per channel	512
Maximum number of remote I/O bases per channel	7
*Max. of 2 D4-RM, 1 channel is via 25-pin CPU port	

### **Serial Remote I/O Master/Slave Modules**

#### Remote Master





Remote Master Specifications		
Module Type	Intelligent device	
Number of Masters per CPU	Three maximum for D4-454	
Maximum Slaves Supported	Seven slaves per channel	
Communication to Slaves	RS485 via twisted pair with shield @ 38.4K baud	
Recommended Cable	Belden 9841 or equivalent	
Transmission Distance	3300 ft maximum	
Terminal Type	Fixed	
Operating Environment	0°C to 60°C (32°F to 140°F), 5% to 95% humidity (non-condensing)	
Internal Power Consumption	300mA maximum	

Remote Slave Specifications			
Maximum Slave Points per CPU	1536 for D4-454		
I/O Addresses Used	I/O modules in slave bases do not automatically consume any standard input and out- put points. They consume remote I/O points at a rate equal to the number of I/O points in each base. However, you can choose to use standard I/O addresses as an option.		
Terminal Type	Fixed		
Operating Environment	0°C to 60°C (32°F to 140°F), 5% to 95% humidity (non-condensing)		
Power Required	110VAC /220VAC (D4-RS)		

#### **Check the Power Budget**

### Verify your power budget requirements

Your I/O configuration choice can be affected by the power requirements of the I/O modules you choose. When determining the types and quantity of I/O modules you will be using, it is important to remember there is a limited amount of power available from the power supply.

The chart on the opposite page indicates the power supplied and used by each DL405 device. The adjacent chart shows an example of how to calculate the power used by your particular system. These two charts should make it easy for you to determine if the devices you have chosen fit within the power budget of your system configuration.

If the I/O you have chosen exceeds the maximum power available from the power supply, you can resolve the problem by shifting some of the modules to an expansion base or remote I/O base (if you are using remote I/O).

Warning: It is extremely important to calculate the power budget correctly. If you exceed the power budget, the system may operate in an unpredictable manner which may result in a risk of personal injury or equipment damage.

#### Use *ZIP*Links to reduce power requirements

If your application requires a lot of relay outputs, consider using the *ZIP*Link AC or DC relay output modules. These modules can switch high current (10A) loads without putting a load on your base power budget. Refer to Wiring System for DL405 PLCs later in this section for more information. This logo is placed next to I/O modules that are supported by the *ZIP*Link connection systems.

See the I/O module specifications at the end of this section.



# Calculating your power usage

The following example shows how to calculate the power budget for the DL405 system. The example is constructed around a single 8-slot base using the devices shown. It is recommended you construct a similar table for each base in your system.

A							
	Base Number O	Device Type	5 VDC (mA)	External 24 VDC Power (mA)			
B	CURRENT SUPPLIED						
	CPU/Expansion Unit /Remote Slave	D4-454 CPU	3700	400			
C	CURRENT REQUIRED						
	SLOT 0	D4-16ND2	+150	+0			
	SLOT 1	D4-16ND2	+150	+0			
	SLOT 2	F4-04DA	+120	+100			
	SLOT 3	D4-08NA	+100	+0			
	SLOT 4	D4-08NA	+100	+0			
	SLOT 5	D4-16TD2	+100	+0			
	<b>SLOT 6</b> D4-16TD2		+100	+0			
	SLOT 7	D4-16TR	+1000	+0			
D	OTHER						
	BASE	D4-08B-1	+80	+0			
	Handheld Programmer	D4-HPP-1	+320	+0			
E	<b>Maximum Current Require</b>	2820	100				
F	Remaining Current Available3700-2820=880400-100=300						
	1. Using a chart similar to the one above, fill in column 2. 2. Using the tables on the opposite page, enter the current supplied and used by each device (columns 3 and 4) Pay special attention to						

2. Using the tables on the opposite page, enter the current supplied and used by each device (columns 3 and 4). Pay special attention to the current supplied by the CPU, Expansion Unit, and Remote Slave since they differ. Devices which fall into the "Other" category (Row D) are devices such as the Base and the Handheld programmer, which also have power requirements, but do not plug directly into the base. 3. Add the current used by the system devices (columns 3 and 4) starting with Slot 0 and put the total in the row labeled "maximum current required" (Row E).

4. Subtract two products of the row labeled "Maximum current required" (Row E), from the row labeled "Current Supplied" (Row B). Place the difference in the row labeled "Remaining Current Available" (Row F).
5. If "Maximum Current Required" is greater than "Current Supplied" in either column 3 or 4, the power budget will be exceeded. It will be

5. If "Maximum Current Required" is greater than "Current Supplied" in either column 3 or 4, the power budget will be exceeded. It will be unsafe to use this configuration and you will need to restructure your I/O configuration. Note the auxiliary 24VDC power supply does not need to supply all the external power. If you need more than the 400mA supplied, you can add an external 24VDC power supply. This will help keep you within your power budget for external power.

#### DL405 CPU power supply specifications and power requirements

Specification	AC Powered Units	24 VDC Powered Units	
Part Numbers	D4-454, D4-EX (expansion base unit), D4-RS (remote slave unit)	D4-454DC-1, D4-EXDC (expansion base unit)	
Voltage Withstand (dielectric)	1 minute @ 1,500 VAC between primary, secondary, field ground, and run relay		
Insulation Resistance	> 10MΩ at 500VDC		
Input Voltage Range	85-132 VAC (110V range) 170-264 VAC (220V range)	20-28 VDC (24VDC) with less than 10% ripple	
Maximum Inrush Current	20A 20A		
Maximum Power	50VA 38W		

## **Power Requirements**

		Powe	er Supplied			
CPUs/Remote Units/ Expansion Units	5 VDC Current Supplied in mA	24V Aux Power Supplied in mA	CPUs/Remote Units/ Expansion Units	5V Current Supplied in mA	24V Aux Power Supplied in mA	
D4-454 CPU D4-454DC-1	3100 3100	400 NONE	D4-EX D4-EXDC D4-RS H4-EBC	4000 4000 3700 3470	400 NONE 400 400	
		Power	Consumed			
Power-consuming Device	5V Current Consumed	External 24VDC Current Required	Power-consuming Device	5V Current Consumed	External 24VDC Current Required	
I/O Bases			Analog Modules (contil	nued)	1	
D4-04B-1 D4-06B-1 D4-08B-1	80 80 80	NONE NONE NONE	F4-16AD-1 F4-16AD-2 F4-04DA-1 F4-04DA-2	75 75 70 90	100 100 75+20 per circuit 90	
DC Input Modules			F4-04DAS-1 F4-08DA-1	60 90	60 per circuit 100+20 per circuit	
D4-16ND2 D4-16ND2F D4-32ND3-1 D4-64ND2	150 150 150 300 max.	NONE NONE NONE NONE	F4-08DA-2 F4-16DA-1 F4-16DA-2 F4-08RTD F4-08THM-n F4-08THM	80 90 80 80 120 110	150 100+20 per circuit 25 max. NONE 50 60	
			Remote I/O			
AC Input Modules						
D4-08NA D4-16NA	100 150	NONE	H4-ERM100 H4-ERM-F D4-RM	320(300) 450 300	NONE NONE NONE	
AC/DC Input Modules	1					
D4-16NE3	150	NONE	Communications and Networking			
DC Output Modules			H4-ECOM100	300	NONE	
D4-16TD1 D4-16TD2	200 400	125 NONE	D4-DCM F4-MAS-MB	500 235	NONE	
D4-32TD1 D4-32TD2	250 350	140 120 (4A max	CoProcessors			
D4-64TD1	800	including loads) NONE	F4 00400 4	005	NONE	
AC Output Modules			F4-CP128-1	305	NONE	
D4-08TA	250	NONE	Specialty Modules			
D4-16TA	450	NONE	_			
<b>Relay Output Modules</b>	1		H4-CTRIO	400	NONE	
D4-08TR F4-08TRS-1 F4-08TRS-2 D4-16TR	550 575 575 1000	NONE NONE NONE NONE	D4-16SIM F4-4LTC	150 280	NONE 75	
Analog Modules			Programming		<u> </u>	
•			D4-HPP-1 (Handheld Prog.)	320	NONE	
F4-04AD	150	100	<b>Operator Interface</b>		·	
F4-04ADS F4-08AD	370 75	120 90	DV-1000	150	NONE	
			C-more Micro-Graphic	210	NONE	